

MACHETTE 49CM ITEM NO. : 44950



Manual for use

Read this manual carefully before use.

Use

The machete is ideal for removing smaller branches, trees or logs, peeling bark from logs and cutting branches from the trunk, in forestry and gardening. Also, for use in hiking, fishing, camping, etc. The non-slip rubber handle allows for a secure grip, absorbs the shock caused by use, reduces fatigue and allows the maximum amount of impact energy to be transferred to the blade of the tool. Made of hardened steel with ground edge. The machete has a hole at the top of the blade so that it can be hung on the wall. It is equipped with a tooth saw on the upper edge. Includes a nylon sheath with Velcro closure.

Do not abuse the machete as a tool, e.g. for prying objects such as a crowbar. This will damage the blade. The blade will be bend and even break off.

Features

Blade, Saw, Hook, Front Blade

Technical data

Technical data - 44590	
Handle Length	19,5 cm
Weight	483 g
Material of the Blade	Stainless Steel, Black oxidated
Material of the Handle	Plastics
Material Belt Holder	600D Polyester

Care Instructions

- After each use. thoroughly clean the blade from dirt and dry the blade
- Never expose the machete to extreme heat while drying. This will cause distortions and cracks on the handle may shrink.
- Lightly tub the entire blade with suitable oil.
- Please refer to specialist literature for sharpening the blade with a sharpening steel, smoothing the blade on an oilstone and for the treatment with sharpening oil.
- Never grind the blade on an emery stone. The blade will burn and become damaged.